

Sapphire 1 & Satin 1 Glass Installation Guide



CHECK THE BATH UPON RECEIPT

Remove ALL packaging and inspect carefully. Claims will NOT be accepted after the bath is installed.

Bath Notes

- The bath has twin wastes (clicker or plug& chain). These can be run independently to a collector, or be joined.
- The panels may be trimmed to achieve a lower step height if required.
- **In order to preserve the life and effectiveness of the door seal, the bath door MUST be left in the open position when not in use.**

Bath Installation

- Fix wooden battens of approximately 50mm thickness onto the floor under the feet.
- Place the bath in position and adjust the feet to suit the panels. Set as low as possible to ensure the lowest possible step height.
- Ensure that the bath is set absolutely true and level.
- Fit the TMV, taps and waste. Connect inlet pipes and run to a position where they can be accessed later.
- Secure the bath to the floor and walls.
- **DO NOT CAUSE THE BATH TO FLEX WHEN SECURING IT TO THE WALL AND FLOOR.**
- Connect up the water supplies. Always fit a thermostatic blending valve.
- Connect waste.
- Test the water temperature (should be approx 44 degrees) and water tightness of the installation and door.
- If a spa is fitted, test as described in the manufacturer's notes.
- Fit battens to the floor and fit the panels into the panel clips fixed to the bath.
- Apply silicone sealant. Do not silicone the front panel as access may be required for maintenance of the TMV.

Fitting the optional extension box

After the removal of the old bath, an area of wall or floor may be exposed as the new tub bath is shorter. A GRP extension box can be provided to cover these areas. Trim the box then fix in place by applying battens to the wall and floor.