



Satin Bath Installation Guide

The Satin Shower Bath is supplied with the following components:-

- Front panel and shower screen, 2 x wall brackets, 2 x bath feet (supplied loose), waste kit
- Optional Item: End panel (not-handed)

Other Items Required

Thermostatic Mixing Valve - **MUST BE INSTALLED IN ALL CASES.**

Bath filler or bath shower mixer

IMPORTANT NOTES

- The Satin has 7 adjustable feet. 5 are fitted and 2 outrigger legs are supplied loose.
- To avoid the risk of scalding, the hot water supply must be thermostatically controlled.
- Twin wastes are fitted to aid drainage and to ensure the bath can be drained if one waste fails.
- The bath must be installed rigidly to ensure there is no movement when the bath is used.
- If fitting in an alcove ensure the bath goes freely into position. Sideways pressure can distort the door opening.

The Satin is manufactured in glass fibre. Handle with care. The bath edges are more brittle than acrylic baths.

Fitting Guide

- 1) Manoeuvre bath into position.
- 2) Secure the 2 bath feet supplied loose to the plastic sockets underneath the bath.
- 3) Drill the bath and fit taps.
- 4) Fit wastes, overflows and waste traps.
- 5) Place bath in position and adjust to minimum height.

Note: It is advisable to fix batten runs on to the floor under the bath feet to avoid extending the legs too far and to ensure feet sit square and flat. On a wooden floor batten runs (3" x 2" minimum) should be positioned squarely across the floorboards to spread the load.

- 6) Level the bath in all planes using the 7 adjustable feet, then lock the feet. Ensure the bath foot under the doorway is adjusted up to support the footwell.
- 7) Mark wall fixings and plumbing runs.
- 8) Remove the bath. Drill for wall fixings where accessible and run plumbing into position.
- 9) Reposition the bath and fix to the floor via bath feet.
- 10) Connect plumbing. Refer to fitting and setting up guide for the thermostatic valve.
- 11) Test plumbing for leaks.
- 12) Fill the bath to maximum and leave for about 20 minutes to test the door seal.
- 13) While the bath seal is being tested, position and trim to size the front and end panels.
- 14) Mark the bottom of the panels onto floor base. Fix battens along the floor behind the panels.
- 15) Fit the front and end panels. Drill through into the batten at the foot and into the bath wooden frame at the top. Push fit the panels onto the retaining clips prefitted on the bath sides. Do not use silicone sealant as this prevents service access.
- 16) Silicone seal the bath rim to walls as necessary.
- 17) Install the shower screen following the instruction sheet packed with the screen.

The door should be left open when not in use in order to preserve the seal.

May 2016